

A United Volleyball Supply, LLC. Company • 14615 NE 91st ST, Bldg B, REDMOND, WA 98052 • 1996-2007© VOLLEYBALLUSA.COM
PH: 1-800-494-3933 • FAX: 425-827-2230



Maintain a beautiful edge between your sand and grass.



Mounts directly on top of treated 2x12 with cushion gap.



Easy overlap installation.
No cutting need.



Sand stays soft on one side and grass stays beautiful on the other.

- For construction, lay sections of 2x12 treated wood to outline the edge of your court. Sink the 2x12's into the ground so that the board is an inch below the surface. The goal is to use the Edge Guard as a cushion but not to make it a trip hazard.

- Take your edge guard and lay it out over the 2x12 before screwing them in. This will ensure you will have enough material and won't have to order more. Overlap edge guard 4 inches and fasten with two screws, one on each side, as necessary for the perimeter of your court.

- Use 1" pan head screws every foot to secure your edge guard on both sides of the 2x12. We recommend a 1" galvanized or stainless steel pan head screw.

- Corners require two 45 degree cuts on site or can be provided with the order for an extra \$100 charge. We like to use a sacrificial piece of wood to hold the Edge Guard open in it's installed shape when cutting. We recommend running a clear silicone bead over the corner joints and overlaps to lock them together.

Stay away from extreme cold and extreme hot conditions.
Do not set or lay any heavy materials on the Edge Guard for an extended period of time.

For additional help call 1-800-494-3933