



Instructions for setting up your Wood Pole Attachment System

- 1 - Attach tracks to flat surface about 36' apart.
- 2 - Adjust eye bolt height by turning eye bolts and moving to desired height.
- 3 - Once eye bolts are secure, locate top net cable and attach carabiner clip to net loop.
- 4 - Attach the same carabiner clip to eye top bolt on track B.
- 5 - On track A, attach the same top net cable to the carabiner clip on end of ratchet strap.
- 6 - Tighten ratchet by repeatedly opening and closing ratchet hardware.
 If desired net tension is not reached, shortening of net cables may be necessary
- 7 - To tighten the bottom of your net, repeat steps 2-6 using bottom cables with bottom eye bolts and bottom ratchets.

If you have any questions, please call 1-800-494-3933.

United Volleyball Supply, LLC
14615 NE 91st St. Bldg. B
Redmond, WA 98052
PH: 425-576-8835 E-Mail: info@volleyballusa.com