



A United Volleyball Supply, LLC. Company • 14615 NE 91st ST, Bldg B, REDMOND, WA 98052 • 1996-2007© VOLLEYBALLUSA.COM

PH: 1-800-494-3933 • FAX: 425-827-2230



VB-RAG System Parts Check List:

- Qty. 2 - Roll-a-way bases and poles (A) (2 Extra carabineer clips for quick net connection)
- Qty. 2 - Eyebolt collars (B) for net connection and height adjustment
- Qty. 2 - Quick tension collars (C) for net tension and height adjustment.
- Qty. 2 - Guy wire support lines (D) with cam buckle components for added pole stability/net tension.
- Qty. 2 - Suction Cups (E) for guy wire floor attachment.



SUCTION CUP

(E)

PADDING AVAILABLE FOR POLES AND BASES

Step by step setup instructions:

1) Please begin by assembling your roll away poles and bases following the **ROLL AWAY POLE INSTRUCTIONS**.

2) If you haven't already, attach the **QUICK TENSION COLLARS (C)** to the **POLE** by loosening the **SET SCREW** on the back of the **QUICK TENSION COLLAR (C)**, as shown on front page.

3) To attach the net to **ROLL AWAY POLES**, begin by identifying whether you have a rope or steel cable running through the top and bottom of your net. See **LOOP KNOT INSTRUCTIONS** for rope material or the **U-BOLT / CABLE CLAMP** instructions for steel cable.

4) Attach both the top and bottom through ropes to the eyebolt connection collars as shown on the right side of the diagram on page 1 using provided carabineer clips. Note that loops will be needed.

5) The **QUICK TENSION COLLARS (C)** come complete with **CARABINEER CLIPS** already attached to the **NET CONNECTION STRAP**. Attach the **TOP THROUGH ROPE** to the **QUICK TENSION COLLAR (C)**. (Calibration of through ropes will fluctuate due to pole to pole distance. Volleyball USA sends through ropes with longer lengths to insure quality initial setup)

6) **REPEAT STEP 5** for the bottom through rope attaching it to the quick tension collar.

7) The **GUY WIRE SUPPORT LINES** come constructed with a pre made loop ends. Loop one end around the top of the pole so that it rests on the collar. The other end of each **GUY WIRE SUPPORT LINE** will clip to the provided suction cups via a **CARABINEER CLIP**.

8) Walk **SUCTION CUP** away from court until slack on **GUY WIRE** is relinquished. Then follow **SUCTION CUP INSTRUCTIONS** to create suction to floor. Distance of suction cup to pole will differ from gym to gym.

9) After suction is created, pull down on the **GUY WIRE SUPPORT LINE STRAP** to create pole tension and added stability. (You will have to alternate sides of court once or twice.)

10) Once **ROLL AWAY POLES** have been stabilized, you can increase net tension by then pulling down on the **QUICK TENSION COLLAR STRAPS (C)** attached to the top and bottom through ropes until sufficient net tension is reached.

PLEASE NOTE THAT EXTRA NET SIDE BRACING STRAPS/ROPES MAY BE ORDERED